

## NOTES

- 1. THIS DOCUMENT PROVIDES INFORMATION TO PREPARE THE INSIDE SURFACE OF A DOOR
- & THE DOOR FRAME FOR AN 8500 SERIES RIM EXIT DEVICE INSTALLATION
- 2. EXIT DEVICE INSTALLATION SURFACE MUST BE FLAT WITHIN 1/32"
- 3. RE-ENFORCEMENT IS RECOMMENDED AT THE EXIT DEVICE ATTACHMENT AREAS
- 4. IF EXTERIOR TRIM IS USED, REFER TO THE TRIM INSTALLATION TEMPLATES FOR THE EXTERIOR DOOR SURFACE PREPARATION

ALL DIMENSIONS ARE IN INCHES DO NOT SCALE DIMENSIONS ON DRAWING

TOLERANCES		CANAROPA			
DIMENSIONS	DEGREES	DRAWN	DATE	TITLE	
± 1/64"	± 0.5	СС	Ø1-APR-14	SERIES 8500	
MATERIAL		APPR'D	DATE Ø1-APR-14	RIM EXIT DEVICE  DOOR PREP	
N/A			WI-HFK-14		
FINISH N/A		APPR'D	DATE	SCALE	DWG NO
IV FI			27-AUG-14	REV -C-	CAN-8500-RIM-DP