



PICTORIAL FOR LH DOOR BOTTOM EDGE CUT  
MIRROR FOR RH DOOR BOTTOM EDGE CUT

DIMENSIONS MM  
[INCHES]

DO NOT SCALE DIMENSIONS ON DRAWING

NOTES:

1. REMOVE ALL SHARP EDGES
2. ENSURE SMOOTH TRANSITION BETWEEN CURVES AND BETWEEN CURVES AND STRAIGHT LINES
3. WE RECOMMEND THAT PHYSICAL HARDWARE BE ORDERED AND VERIFIED BEFORE STARTING ANY PREPARATION, MANUFACTURING OR INSTALLATION WORK.

TOLERANCES					1725 50TH AVENUE, LACHINE, QUEBEC, H8T 3C8 TELL: +1 (888) 636 6466 WWW.CANAROPA.COM	
INCHES	MM	DEGREES	DRAWN	DATE	TITLE GLASS CUT FOR DOOR CLOSER SERIES PF100DC, PF102DC	
± 0.02	± 0.5	± 0.5	K.S	2022/04/21		
MATERIAL			APPR'D	DATE	SCALE 1:1 DWG NO	
GLASS DOORS			C.C	2022/04/21		
FINISH			APPR'D	DATE	REV -	CAN-PF100DC-102DC-GC
NONE						

THIS DRAWING AND THE INFORMATION CONTAINED THEREON OR DERIVED THERE FROM ARE THE CONFIDENTIAL PROPERTY OF CANAROPA, IT IS NOT TO BE REPRODUCED OR DISCLOSED TO OTHERS, WITHOUT PRIOR WRITTEN CONSENT FROM CANAROPA.